



## Personal Protective Equipment (PPE)

SAND No. 2009-8386P  
Sandia is a multiprogram laboratory operated by Sandia Corporation, a Lockheed Martin Company,  
for the United States Department of Energy's National Nuclear Security Administration  
under contract DE-AC04-94AL85000.



## Limitations of PPE

- The least desirable control, but may be necessary if:
  - Engineering controls are being installed
  - Emergency response/spill cleanup
  - Non-routine equipment maintenance
  - To supplement other control methods
- Problems with PPE:
  - The hazard is still present with PPE
  - Use is very dependent on human behavior
  - Proper fitting is essential
- Can exposure be controlled by other means?



## Personal Protective Equipment (PPE)

- Limitations of PPE
- Hazard assessment
- Training
- Characteristics of PPE
- Protective clothing
- Gloves
- Eyewear
- Respirators
- Exercise



## PPE Hazard Assessment

- Identify the hazard(s)
  - Chemical
  - Mechanical
  - Electrical
  - Light energy (lasers, welding)
  - Fire response
  - Hot processes
- Identify the potential exposure route
  - Inhalation
  - Skin contact
  - Eye contact





## PPE Hazard Assessment

- Identify the type of skin contact
  - Immersion
  - Spray
  - Splash
  - Mist
  - Vapor (gaseous)
- Consider the exposure time
  - Incidental contact
  - Continuous immersion
  - Unknown/emergency response



## Training

Employees should be trained to know:

- When PPE is necessary
- What PPE is necessary
- How to properly don, doff, adjust and wear PPE
- Limitations of PPE
- Proper care, maintenance, useful life and disposal
- Involve workers in selection



<http://www.free-training.com/OSHA/ppe/Ppemenue.htm>



## Exercise

- List one work activity at your plant that uses PPE
- What is the hazard?
- What is the route of exposure? Inhalation, skin, eyes, or ?
- Are there ways to control exposure to this hazard other than PPE?
  - What other ways?



## Training

Retraining is necessary when there is:

- A change in the hazards
- A change in the type of PPE required
- Inadequate employee knowledge or use of PPE



<http://www.free-training.com/OSHA/ppe/Ppemenue.htm>



## General Characteristics of PPE

### Protective clothing and gloves:

- Act as a barrier to prevent contact with the skin
- Protect against
  - Toxics
  - Corrosives
  - Irritants
  - Sensitizers (allergens)
  - Thermal injury (burns)
  - Physical Trauma



Permeation Rate (PR)	Permeation Breakthrough (PB)	Permeation Degradation rate (DR)
<b>E</b> - Excellent; permeation rate of less than 0.9 mg/cm <sup>2</sup> /min	<b>&gt;</b> Greater than (time - minutes)	<b>E</b> - Excellent; fluid has very little degrading effect.
<b>VG</b> - Very Good; permeation rate of less than 9 mg/cm <sup>2</sup> /min	<b>&lt;</b> Less than (time - minutes)	<b>G</b> - Good; fluid has minor degrading effect.
<b>G</b> - Good; permeation rate of less than 90 mg/cm <sup>2</sup> /min		<b>F</b> - Fair; fluid has moderate degrading effect.
<b>F</b> - Fair; permeation rate of less than 900 mg/cm <sup>2</sup> /min		<b>P</b> - Poor; fluid has pronounced degrading effect.
<b>P</b> - Poor; permeation rate of less than 9000 mg/cm <sup>2</sup> /min		<b>NR</b> - Fluid is not recommended with this material.
<b>NR</b> - Not recommended; permeation rate greater than 9000 mg/cm <sup>2</sup> /min		↑ Not tested, but breakthrough time > 480 min DR expected to be Good to Excellent
		↑↑ Not tested, but expected to be Good to Excellent based on similar tested materials



## General Characteristics of PPE

### Protective clothing and gloves

- When selecting consider:
  - Permeation
    - Breakthrough time
    - ASTM F739 Standard
  - Penetration
  - Degradation
  - Comfort
  - Heat stress
  - Ergonomics
  - Cost




Photo credit: Permeation, <http://www.cdc.gov/niosh/topics/skin/>



## Protective Clothing

- Special Applications
  - Hot processes
  - High voltage/arc flash
    - NFPA 70E
  - Foundries/molten metal
  - Refineries
- Select flame resistant clothing
- Chemical resistant coating may be added to flame resistant clothing



## Gloves

- Evaluate the work task
  - Chemical immersion or incidental contact?
  - Consider ergonomics/dexterity required
- Use glove charts
  - Charts recommend gloves for specific chemicals
    - Evaluate permeation rates and breakthrough time of selected glove for the specific task
  - Consider several glove manufactures data before final selection.
    - <http://www.mapaglove.com>
    - <http://www.ansellpro.com>
    - <http://www.bestglove.com/site/chemrest/>



## General Types of Glove Material

### Laminated Gloves: 4H®, Silver Shield®

- Useful for a wide range of chemicals.
- NOT HYDROGEN FLUORIDE!**
- Can use with a nitrile over glove to improve dexterity.



### Butyl Rubber

- Highest permeation resistance to gas or water vapors.
- Uses: acids, formaldehyde, phenol, alcohols.



The first square in each column for each glove type is color coded. This is an easy-to-read indication of how we rate this type of glove in relation to its applicability for each chemical listed. The color represents an overall rating for both degradation and permeation. The letter in each square is the Degradation alone.

GREEN: The glove is very well suited for application with that chemical.

YELLOW: The glove is well able for that application under careful control of its use.

RED: Avoid use of the glove with this chemical.

CHEMICAL	LAMINATE FILM		NITRILE		UNSUPPORTED NEOPRENE		SUPPORTED POLYVINYL ALCOHOL		POLYVINYL CHLORIDE (PVC)		NATURAL RUBBER		NEOPRENE/NATURAL RUBBER BLEND	
	BARRIER	SOL-VEX	29-865	PVA	SNORKEL	CANNERS AND HANDLERS*	CHEM-PRO®	BARRIER	SOL-VEX	29-865	PVA	SNORKEL	CANNERS AND HANDLERS*	CHEM-PRO®
1. Acetaldehyde	380	E	10	F	NR	NR	NR	NR	NR	NR	NR	NR	NR	NR
2. Acetic Acid	150	G	270	E	60	NR	NR	NR	NR	NR	NR	NR	NR	NR
3. Acetone	<480	E	NR	NR	10	F	NR	NR	NR	NR	NR	NR	NR	NR
4. Acetonitrile	<480	E	30	F	20	G	150	G	NR	NR	NR	NR	NR	NR
5. Acrylic Acid	NR	G	120	NR	390	NR	NR	NR	NR	NR	NR	NR	NR	NR
6. Acrylonitrile	<480	E	NR	NR	NR	NR	NR	NR	NR	NR	NR	NR	NR	NR
7. Ethyl Alcohol	<480	E	140	F	140	VG	NR	NR	NR	NR	NR	NR	NR	NR
8. Ammonia Gas	19	E	<480	NR	<480	NR	NR	NR	NR	NR	NR	NR	NR	NR
9. Ammonium Fluoride, 40%	NR	E	<360	NR	<480	NR	NR	NR	NR	NR	NR	NR	NR	NR
10. Ammonium Hydroxide	30	E	<360	NR	250	NR	NR	NR	NR	NR	NR	NR	NR	NR
11. Amyl Acetate	<480	E	60	G	NR	NR	G	<360	NR	NR	NR	NR	NR	NR
12. Amyl Alcohol	NR	E	30	E	290	VG	G	180	G	12	E	25	VG	45
13. Aniline	<480	E	NR	NR	100	P	F	<360	NR	NR	NR	NR	NR	NR
14. Aqua Regia	NR	F	<360	NR	<480	NR	NR	NR	NR	NR	NR	NR	NR	NR
15. Benzaldehyde	<480	E	NR	NR	NR	NR	G	<360	NR	NR	NR	NR	NR	NR
16. Benzene, General	<480	E	NR	NR	NR	NR	E	<360	NR	NR	NR	NR	NR	NR
17. Benzotrifluoride	NR	E	<480	E	NR	NR	NR	NR	NR	NR	NR	NR	NR	NR
18. Bisoxazolone	NR	E	170	G	NR	NR	NR	NR	NR	NR	NR	NR	NR	NR
19. Bromine Water	NR	E	<480	E	<480	NR	NR	NR	NR	NR	NR	NR	NR	NR
20. 1-Bromopropane	<480	E	23	F	<10	P	<480	NR	NR	<10	F	<10	P	<10

## Types of Gloves

### Neoprene

- Protects against acids, caustics.
- Resists alcohols, glycols.

### Nitrile

- Good replacement for latex
- Protects against acids, bases, oils, aliphatic hydrocarbon solvents and esters, grease, fats
- NOT ketones
- Resists cuts, snags, punctures and abrasions





## Eye and Face Protection

- Each day, 2000 U.S. workers have a job-related eye injury that requires medical treatment.
- Nearly *three out of five* U.S. workers are injured while failing to wear eye and face protection.

NIOSH. (2010). <http://www.cdc.gov/niosh/topics/eye/>

## Proper Steps for Removing Gloves

- 1
- 2
- 3
- 4
- 5
- 6

## Types of Eye Hazards

Hazard Type	Common related tasks	Protective Eyewear
Impact	Chipping, grinding, machining, abrasive blasting, sawing, drilling, riveting, sanding,...	Safety glasses with sideshields Goggles
Heat	Furnace operations, smelting, pouring, casting, hot dipping, welding, ...	Face shield with infrared protection
Chemicals	Pouring, spraying, transferring, dipping acids, solvents or other injurious chemicals	Goggles Faceshield
Particles/ Dust	Woodworking, metal working, and general dusty conditions	Safety glasses with sideshields
Optical Radiation	Welding, torch-cutting, brazing, and laser work	Welding helmet Laser glasses -Must protect for specific wavelength of ultraviolet or infrared radiation.

## Examples of Eye & Face Protection




- Goggles
- Face shield
- Safety glasses
- Welding helmet
- Hooded faceshield



## Basic Types of Respirators

- Air purifying (APR)
  - Half Face
  - Full Face
  - Powered APR (PAPR)
- Air supply
  - Air line
  - SCBA



## Respiratory Protection

### U.S. Respirator Requirements


- Written program
- Hazard assessment
  - Air monitoring
- Medical clearance
- Fit testing
- Respirator selection
- Procedures
  - Cleaning, maintenance, repairing
- Training (annual refresher)






## Air Purifying Respirators (APR)


- Work area must have at least 19.5% oxygen
- The contaminant must have adequate warning properties. Ex. ammonia
  - **Never** use APR in oxygen deficient atmospheres
- APRs work by filtering, absorbing, adsorbing the contaminant or chemical reaction.
  - Filters, cartridges, canisters
- The contaminant concentration must NOT exceed the maximum use concentration.
- Some cartridges have “end of service life” indicators or can use change schedules







## Types of APR Cartridges

Cartridge	Description
	Organic Vapor
	Organic Vapor and acid gases
	Ammonia, methylamine and P100 particulates filter










## APR Filter Efficiency

National Institute of Occupational Safety and Health  
Filter Efficiencies

Filter Class	
<b>N95</b>	Filters at least 95% of airborne particles. Not resistant to oil.
<b>N99</b>	Filters at least 99% of airborne particles. Not resistant to oil.
<b>N100</b>	Filters at least 99.97% of airborne particles. Not resistant to oil.
<b>R95</b>	Filters at least 95% of airborne particles. Somewhat resistant to oil.
<b>P95</b>	Filters at least 95% of airborne particles. Strongly resistant to oil.
<b>P99</b>	Filters at least 99% of airborne particles. Strongly resistant to oil.
<b>P100</b>	Filters at least 99.97% of airborne particles. Strongly resistant to oil.










## End of Service Life Indicators (ESLI)


There are very few NIOSH-approved ESLI's:

- ammonia
- carbon monoxide
- ethylene oxide
- hydrogen chloride
- hydrogen fluoride
- hydrogen sulfide
- mercury
- sulfur dioxide
- toluene-2,4-diisocyanate
- vinyl chloride












## Assigned Protection Factors (APF)

- Level of workplace respiratory protection that a respirator or class of respirators is expected to provide.
- Each specific *type* of respirator has an Assigned Protection Factor (APF).
- Select respirator based on the exposure limit of a contaminant and the level in the workplace.

**Maximum Use Concentration (MUC)**  
**= APF x Occupational Exposure Limit**  
**(e.g. PEL, TLV)**











## Assigned Protection Factors

Type of Respirator	Half Face Mask	Full Facepiece	Helmet/Hood	Loose-Fitting Facepiece
Air-Purifying	10	50	-	-
PAPR	50	1,000	25/1,000	25
Supplied-Air or Airline				
– Demand	10	50	-	-
– Continuous flow	50	1,000	25/1000	25
– Pressure demand	50	1,000	-	-
SCBA				
– Demand	10	50	50	-
– Pressure Demand	-	10,000	10,000	-




**Chemical**  
SAFETY AND SECURITY TRAINING



## Assigned Protection Factors


**Workplace air sampling indicates the exposure to benzene is 15 ppm. The exposure limit is 0.5 ppm (ACGIH TLV). What respirator should you choose?**


**Maximum Use Concentration (MUC) = APF x OEL**


Half Face Mask: MUC = 10 x 0.5 ppm = 5 ppm

PAPR (LFF): MUC = 25 x 0.5 ppm = 12.5 ppm

Full Face Respirator: MUC = 50 x 0.5 ppm = 25 ppm




**Chemical**  
SAFETY AND SECURITY TRAINING







## Respirator Fit Testing

- **Qualitative**
  - Irritant smoke
    - stannic chloride
  - Isoamyl acetate
    - banana oil
  - Saccharin
  - Bitrex
- **Quantitative**
  - Portacount



## Supplied Air

- **Supplies breathing air to worker**
  - SCBA
  - Airline
- **Must use Grade D Air**
- **Many limitations**



## Respirator Fit Test

Positive / Negative pressure fit test



## Breathing Air Quality and Use

- **Compressed breathing air must be at least Type 1 - Grade D [ANSI/CGA G-7.1-1989]:**
  - Oxygen content = 19.5 - 23.5%
  - Hydrocarbon (condensed) = 5 milligrams/cubic meter or less
  - CO  $\leq$  10 parts per million (ppm) or less
  - CO<sub>2</sub> of 1,000 parts per million (ppm) or less
  - Lack of noticeable odor
- **Compressors may be equipped with in-line air-purifying sorbent beds and filters.**



## Maintenance and Storage Procedures

- **Disposable filtering face-piece:**
  - Dispose after use
- **Air purifying respirators:**
  - Discard cartridges based on expiration date, end-of-service life indicator or calculated service life
  - Clean
  - Dry
  - Place in sealable bag (write your name on bag)
  - Contact Safety Office for repairs
- **SCBA:**
  - Inspected monthly
  - Accessible and clearly marked



## Foot Protection

### Types:

- Impact, penetration, compression, steel toe, etc.
- Non-skid, with slip resistant soles.
- Chemical resistant (rubber, vinyl, plastic, with synthetic stitching to resist chemical penetration).
- Anti-static
- Temperature resistant (high or low extremes).
- Electrical protection (non-conducting).
- Water resistant



## Exercise

- A contractor has been hired to sweep out a work area that contains lead dust. The plant safety officer has recommended that the worker don a full-face air purifying respirator with a HEPA filter (P100) during this activity.
- Later that week the plant safety officer observes the worker sweeping without wearing the respirator. When asked why he is not wearing the respirator, the worker states "it is too uncomfortable to wear."
- **What approach should the safety officer take to ensure the worker wears a respirator?**



## Head Protection

Should meet or exceed Z89.1-2003

### Types:

- Bump caps - don't meet ANSI standard, provide minor protection
- Electrical protection to 2200-22,000 volts
- Mining protection
- Classic-- high impact general purpose protection.
- Impact 386 – 454 kilograms
- Penetration ~1centimeter





### PPE Exercise

- Worker A needs to transfer 10 liters of acetone into a hazardous waste drum.
- The safety officer has determined that due to the use of ventilation, the air concentration of acetone is below the exposure limit.
- The worker may have incidental skin contact with the acetone during pouring.
- Prolonged skin exposure to acetone causes dry and cracked skin, but acetone is not normally absorbed through the skin.
- There is also a possibility that the acetone may splash in the worker's face during pouring.



### PPE Exercise

- Worker C is tasked with adding zinc oxide pigment into a mixing bath by hand.
- This task will take 15 minutes.
- Worker C performs this task once every day.
- The safety officer has determined that the airborne concentration during this task is 20 milligrams/cubic meter.
- The short term exposure limit (15 minutes) for zinc oxide is 10 milligrams/cubic meter.
- Zinc oxide powder is mildly irritating to the skin and eyes, but not toxic or corrosive.

What PPE should Worker C wear?



### PPE Exercise

- Worker B is walking back from the break room when he notices a yellow cloud of chlorine coming towards him from the chlorine storage area. He also notices that some of the chlorine has come into contact with water under one of the tanks and formed chlorine hydrate.
- He alerts the emergency response team who arrive at the emergency staging area.
  - Chlorine is a corrosive and toxic gas by inhalation.
  - Chlorine hydrate is corrosive to the skin and eyes.
  - The airborne concentration of chlorine is unknown in this situation.

What PPE should the emergency response team use?




## Industrial Ventilation

SAND No. 2009-8395P  
Sandia is a multiprogram laboratory operated by Sandia Corporation, a Lockheed Martin Company,  
for the United States Department of Energy's National Nuclear Security Administration  
under contract DE-AC04-94AL85000.

## Industrial Ventilation

- Definitions
- Common Terminology
- Purpose
- Hazard Assessment
- General Ventilation
- Local Exhaust Ventilation
- Ventilation Evaluation
- Troubleshooting
- Exercises



American Conference of Governmental Industrial Hygienists  
(ACGIH) Ventilation Manual 27th Edition  
<http://www.acgih.org/store/ProductDetail.cfm?id=1905>



## Common Terminology

**Q** = volume of air in cubic meters

**V** = velocity of air in meters per second

- Duct velocity-velocity required to transport the contaminant
- Face velocity-velocity on the front of an enclosing hood
- Capture velocity-velocity required to capture contaminant at point of generation

**A** = cross sectional area of hood opening in square meters

**X** = distance of ventilation from the source in meters



## Definitions

- **Heating, ventilating and air conditioning (HVAC)**: refers to the distribution system for heating, ventilating, cooling, dehumidifying and cleansing air.
- **Replacement/Supply air**: refers to replacement air for HVAC and local exhaust ventilation.
- **General ventilation**: refers to ventilation that controls the air environment by removing and replacing contaminated air before chemical concentrations reach unacceptable levels.
- **Local exhaust ventilation (LEV)**: refers to systems designed to enclose, or capture and remove contaminated air at the source.



## Purposes of Industrial Ventilation

- **Protect workers from health hazards**
  - Dilute, capture, or contain contaminants
- **Protect workers from hot processes**
  - Ovens, foundries
- **Protect the product**
  - Semiconductor
  - Electronics
  - Pharmaceuticals



Slot Hood



Canopy Hood



Laboratory Fume Hood



## Purposes of Industrial Ventilation

- **Emergency ventilation**
  - Standalone fans
  - Detectors connected to ventilation or scrubber systems
  - Safe room
    - Positive pressure
- **Enclosed vented rooms or cabinets**
  - Gas cabinets
- **Comply with health and safety regulations**



Photo credit: Emergency Responder Products

Photo credit: Advanced Specialty Gas Equipment




## General Ventilation

- **Natural Ventilation:**
  - Useful for hot processes
  - Chimney effect
  - Windows and doors kept open
- **Example: a warehouse opens the windows to create natural ventilation**

$$Q = 0.2 AV$$

A = square meters (area of open doors)  
V = wind speed in kilometers/hour  
Q = estimates the flow rate through the building (m/s)



## Hazard Assessment

- **What are the airborne contaminants?**
  - Particles
  - Solvent vapors
  - Acid mists
  - Metal fumes
- **How do the workers interact with the source contaminant?**
- **Are workers exposed to air contaminants in concentrations over an exposure limit?**
  - \*Requires air monitoring of the task
- **Dilution or local exhaust ventilation?**



Picture Credit : International Labor Organization



## General Ventilation

### Dilution Ventilation

- Heat control
- Dilution of odors, flammables
- Not for control of toxics

### Principles

- Contaminant emissions must be widely dispersed
- Exhaust openings must be near contaminant source
- The worker must not be downstream of contaminant
- Air flow over worker should not exceed 3.5 meters/sec



**Local Exhaust Ventilation (LEV)**

- Use when contaminant concentration cannot be controlled by dilution ventilation or other controls
- Select the type of LEV from hazard assessment
  - Which type is best to capture the contaminant?
    - Enclosed or capture hood?
    - Consider worker's needs
  - What duct transport velocity is required to carry the contaminant? Heavy particles?
  - What face or capture velocity is required?
- Select duct material for the contaminant
- Ensure enough replacement air/adequate fan size

**CSP**  
Chemical  
SAFETY AND SECURITY TRAINING

**Local Exhaust Ventilation**

Volumetric Flow Rate,  $Q = VA$  [Circular Opening]

The diagram shows a tapered duct with an arrow indicating the direction of flow. At the larger left end, the equation  $Q = V_1 A_1$  is written. At the smaller right end, the equation  $Q = V_2 A_2$  is written, illustrating that the volumetric flow rate (Q) remains constant throughout the duct despite changes in velocity (V) and cross-sectional area (A).

$Q$  = Volumetric flow rate, in cubic meters/second  
 $V$  = Average velocity, in meters/second  
 $A$  = Cross-sectional area in square meters

**CSP**  
Chemical  
SAFETY AND SECURITY TRAINING



## Local Exhaust Ventilation

Duct diameter = 1 meter  
 $V = 600$  meters/second  
 What is  $Q$ ?

$Q = VA$

$Q = (600 \text{ m/s})(\pi[1\text{m}]^2/4)$

$Q = 471 \text{ meters}^3/\text{second}$

Duct diameter = 0.5 meter  
 What is the duct velocity ( $V$ )?

$Q = VA$

$471 \text{ meters}^3/\text{s} = V(\pi[0.5\text{m}]^2/4)$

$V = 2400 \text{ meters/second}$

For circular ducts  
 $A = \pi d^2/4$

HOOD TYPE	DESCRIPTION	ASPECT RATIO, W/L	AIR FLOW
	SLOT	0.2 OR LESS	$Q = 3.7 LVK$
	FLANGED SLOT	0.2 OR LESS	$Q = 2.6 LVK$
	PLAIN OPENING	0.2 OR GREATER AND ROUND	$Q = V(10K^2 + A)$
	FLANGED OPENING	0.2 OR GREATER AND ROUND	$Q = 0.75V(10K^2 + A)$
	BOOTH	TO SUIT WORK	$Q = VA = VMH$
	CANOPY	TO SUIT WORK	$Q = 1.4 PVD$ SEE FIG. V8-99-03 P = PERIMETER D = HEIGHT ABOVE WORK
	PLAIN MULTIPLE SLOT OPENING 2 OR MORE SLOTS	0.2 OR GREATER	$Q = V(10K^2 + A)$
	FLANGED MULTIPLE SLOT OPENING 2 OR MORE SLOTS	0.2 OR GREATER	$Q = 0.75V(10K^2 + A)$

ACGIH Ventilation Manual

## Local Exhaust Ventilation



**Capture of contaminant is only effective within one (1) duct diameter**

## Local Exhaust Ventilation

**Capture Velocity ( $V$ ): [Plain Opening]**


$Q = V(10x^2 + A)$   
 $X = \text{distance of source from hood face}$



Recommended Capture Velocities		
CONDITION	EXAMPLES	CAPTURE VELOCITY Range in meters/second
No velocity, Quiet air	Evaporation from tanks, degreasers	0.25 – 0.5
Low velocity, moderately still air	Spray booths, container filling, welding, plating	0.5 – 1.0
Active generation into rapid air motion	Spray painting (shallow booths), crushers	1.0 – 2.5
High initial velocity into very rapid air motion	Grinding, abrasive blasting, tumbling	2.5 – 10.1



 ACGIH Ventilation Manual



## Local Exhaust Ventilation

- **Canopy hood:**
  - Best for controlling hot processes
  - Not good for capturing dusts, or vapors
  - Not good where cross-drafts exist
  - Worker must not put head under canopy









Recommended Duct Velocities		
CONTAMINANT	EXAMPLES	DUCT VELOCITY Meters/second
Vapors, gases, smoke	Vapors, gases, smoke	5.0 – 10.1
Fumes	Welding	10.1 – 12.7
Very fine dust	Cotton lint	12.7 – 15.2
Dry dusts & powders	Cotton dust	15.2 – 20.3
Industrial dust	Grinding dust, limestone dust	17.8 – 20.3
Heavy dust	Sawdust, metal turnings	20.3 – 22.9
Heavy/moist dusts	Lead dusts, cement dust	> 22.9



 ACGIH Ventilation Manual

## Local Exhaust Ventilation

- **“Elephant trunk”:**
  - Good for welding fumes, small process tasks, machining, disconnecting process lines
  - Place close to contaminant
  - Ensure adequate capture velocity at distance from contaminant
  - Flanged opening captures contaminant better









## Local Exhaust Ventilation

### • Downdraft hood:

- Vapors pulled down through grill
- Capture velocity depends on source distance from grill
- Not for hot operations



## Local Exhaust Ventilation

### • Fume hood:


- Laboratory use
- Best for small amounts of chemicals
- Sash must be kept at set level
- NO storage of equipment in the hood!



## Local Exhaust Ventilation

### • Slot ventilation:

- Best for liquid open surface tanks
  - Acid baths
  - Plating tanks
- Pulls air across the tank away from worker
- Side enclosures prevent cross drafts
- Push-Pull design is optional (push jet)



## Local Exhaust Ventilation

### • Enclosures:

- Example:
  - Paint booths
- Control of exposure to liquid aerosols and vapors
- Flammability hazard
- Must have scheduled filter changeout
- Operator must be upstream



Photo Credit: Spray Shield Industries





## Local Exhaust Ventilation

### • Other vented enclosures

- Glove boxes
- Furnaces/ovens
- Abrasive blasting



Photo credit: Borel Furnaces and Ovens



Photo credit: U. S. Department of Labor, OSHA




## Ventilation System Evaluation

- Evaluate capture velocity
  - Quantitatively-anemometers, velometers
  - Qualitatively-smoke tubes,
    - Visualizes air movement
    - Use water vapor for clean rooms



Photo Credit: All Products Inc.



## Local Exhaust Ventilation

### Exhaust Systems:

- Do not place exhaust stack near air intakes
  - Re-entrains contaminants into the building
- Do not use rain caps
- Stack height depends on:
  - Contaminant temperature
  - Building height
  - Atmospheric conditions
  - Discharge velocity
  - Ideal discharge velocity is 15 meters per second



## Ventilation System Evaluation

- Air velocity measurements
  - Measure air velocities (meter/sec) at a number of points
  - Average the results and determine volumetric flow rate:  $Q = VA$
  - All instruments must be calibrated periodically
  - Types:
    - Swinging vane velometer
    - Hot-wire anemometer





## Troubleshooting

- Wrong hood for process
  - Example: canopy hood for toxics
- Insufficient capture velocity
- Insufficient duct velocity
  - ~14 meters/second for vapors
  - ~18 meters/second for dust
- Too much air flow = turbulence
- Traffic or competing air currents
- Insufficient make up air
  - Negative pressure
  - Can't open doors



## Exercise

- What is the preferred ventilation system for the following situation?
    - Acid processing bath with open surface area
- A) Lab fume hood  
B) Slot ventilation  
C) Elephant trunk  
D) Canopy hood  
E) Paint booth



## Exercise

- What is the preferred ventilation system for the following situation?
    - Dilute non-toxic odors in the warehouse
- A) General ventilation  
B) Local exhaust ventilation



## Exercise

- What is the preferred ventilation system for the following situation?
    - Welding table
- A) Lab fume hood  
B) Slot ventilation  
C) Elephant trunk  
D) Canopy hood  
E) Paint booth





## Exercise

---

- What is the preferred ventilation system for the following situation?
    - Chemical analysis of small samples for quality control
- A) Lab fume hood  
B) Slot ventilation  
C) Elephant trunk  
D) Canopy hood  
E) Paint booth



## US Standards & Guidelines

---

### ACGIH

American Conference of Governmental Industrial Hygienists  
*Industrial Ventilation, A Manual of Recommended Practice*

### AIHA

American Industrial Hygiene Association  
*Standard Z9.2, Fundamentals Governing the Design and Operation of Local Exhaust Ventilation Systems*

### ASHRAE

American Society of Heating, Refrigeration and Air Conditioning Engineers  
*Standard 62.1-2010, Ventilation for Acceptable Indoor Air Quality*

### OSHA

Occupational Safety and Health Administration  
*Ventilation, 29 Code of Federal Regulations 1910.94*  
<http://osha.gov/>



## Exercise

---

- What is the preferred ventilation system for the following situation?
    - Spray painting a large piece of equipment
- A) Lab fume hood  
B) Slot ventilation  
C) Elephant trunk  
D) Canopy hood  
E) Paint booth

